

# Light-O-Rama




ShowTime  
MP3 Director  
Show Director with MP3 Player

**DC-MP3**

[www.lightorama.com](http://www.lightorama.com)

- Plays MP3s while directing a network of Light-O-Rama controllers
- Stereo line outputs to drive your audio system
- Eliminates the need for a Windows PC to run shows
- Uses an SD card to store animation sequences and MP3 music files
- Can be used standalone or fits inside and is powered by an LOR1602W lighting controller
- Construct a complex show with musical and non-musical animations using the Light-O-Rama Showtime Windows software, then transfer the show to an SD card
- Runs the SD card show continuously as long as the card is inserted and the DC-MP3 is powered
- Contains a date and time clock with capacitor backup to run shows automatically (future firmware release)



**DC-MP3 director card shown with SD card inserted**  
**5 3/8" w x 3/4" h x 3" d**

Now you can run your show without a Windows PC. Great for commercial and/or outdoor applications where there is no place for a Windows PC. The MP3 Director will play the lighting animation sequence files and their associated MP3 music files.

SD cards up to 2 GB are supported. For 128Kbs encoded MP3 music files and average size corresponding sequence files, you can conservatively figure about 2 MB/minute, so a 128 MB card would give you space for a musical show of about an hour. When the show completes, the MP3 Director starts it from the beginning.

Pop out the SD card at anytime and insert another to switch shows. It will start the new SD card show as soon as the card is inserted.

Can be powered by the controllers, so you just turn on power to the controllers to start the show. Or, if the controllers are continuously powered, it can be powered by a 12VDC power brick that you would turn on and off to control the show.



**LOR1602MP3 package**  
**Shown with cover removed**

**Includes 128 MB SD card and  
USB SD card reader/writer for PC**

Compatible SD Cards	Lexar Media
	SimpleTech

Light-O-Rama, Inc.  
Tel: 973-772-6865 Fax 973-772-6128  
[info@lightorama.com](mailto:info@lightorama.com)